

## User's manual – LCD wall pad controller for IZY, UB and BB marine air conditioners

### 1. PREFACE


This manual provides useful information on the LCD wall pad remote controller used for Thermowell boat air conditioning units. Please read carefully this manual before operation and preserve it in a safe place for further consulting.

### 2. CONTROL PANEL

Control panel allows to set all function parameters related to the operation of the air conditioner and particularly:

- Setting operation mode
- Showing set parameters (temperature, fan , etc.)

Control panel shows as follows.



### 3. OPERATION INSTRUCTIONS

#### 3.1. On/Off

- Press  to start or stop the air conditioner.
- LED turns to green colour if system is on and red colour if system is off. If there is timer setting, LED flashes with green colour.

#### 3.2. Temperature setting

- Press  or  to decrease or increase the set temperature. When any of these buttons is pressed, temperature display area will flash with the old temperature setting for 4 seconds. Should there be no further key press it will then return to room temperature display.
- Press  and  together for 5 seconds will change the temperature setting from C to F. Valid temperature set range is 16C~30C or 60F~85F.
- Temperature setting is bypass in Fan mode.

#### 3.3. Mode setting

Press  button to change the operation mode as follow:  
Cool → dry → fan → heat → auto cool/heat

#### 3.4. Fan speed setting

- Press  button to change the fan speed: Auto → Low → Medium → High. Auto fan setting is bypass in Fan mode. Fan speed setting is bypass in dry mode.
- Fan speed setting is not allowed for single speed model.

#### 3.5. Clock and day setting

- Press  key to select function governed by sub-menu dot A and it flashes.

- Press  to change the day setting from Sunday to Saturday.
- Press  or  to change the real time clock [RTC] setting and symbol  lights up. RTC setting can be changed after hold down  or  for 5 seconds.
- Holding down the button will change the setting in a faster speed.
- System will exit this mode automatically 6 seconds after last key press.

### 3.6. On and off timer setting

- Press  key to activate function governed by sub-menu dot A and it flashes.
- Press  to select either on timer or off timer is currently required to program.
- ON symbol and day of week flashing if on timer is selected.
- OFF symbol and day of week flashing if off timer is selected
- Press  to change the day on or off timer setting required from Sunday to Saturday.
- If on timer for this day is empty, timer display area shows , otherwise the on or off timer setting will be shown.
- Press  or  button to change the on or off timer setting. Holding down the button will change the setting in a faster speed.
- Press  key to cancel the current on or off timer selected and the timer display area shows .
-  lights up indicating if there is timer being programmed and the corresponding ON or OFF will also lights up.
- Should there be no further key press, system will exit from on or off timer programming mode 6 seconds later.

### 3.7. Cancel all timer setting

- In on or off timer programming mode, hold down  and  key for 5 seconds will cancel all the on or off timer being programmed.

### 3.8. Sleep setting

- Press  key to select function governed by sub-menu dot B and it flashes.
- Press  to activate or deactivate sleep setting. Sleep is bypass in Fan and Dry mode.
- Should there be no further key press, system will exit from this mode 6 seconds later.

### 3.9. Key lock

- In order to prevent unauthorized access to the system setting, a key lock function is provided to prevent mischief.
- Hold down  and  buttons for 3 seconds to activate the key lock function, key lock symbol  will light up. Repeat the same sequence to cancel key lock function.
- Only  button press is acknowledged.

### 3.10. Error code display

- Should there be any fault happen with the main board, the relevant error code will be shown on the error display area and symbol ERR  will light up.
- If there is multiple faults happen at the same time, the error code will be shown one after another.
- Depends on the model of main board, the error codes available are:

COD.	DESCRIPTION	REASON	SOLUTION
E1	S1 probe broken or not properly connected (White Room)	<ul style="list-style-type: none"> <li>• Broken circuit board</li> <li>• False contact on connections</li> <li>• Erroneous electrical connections</li> <li>• Broken probe</li> </ul>	<ul style="list-style-type: none"> <li>• Check electrical connections</li> <li>• Check electrical connections integrity</li> <li>• Replace the probe</li> </ul>
E2	S2 probe broken or not properly connected (Yellow Indoor)	<ul style="list-style-type: none"> <li>• Erroneous electrical connections</li> <li>• False contact on connections</li> <li>• Broken probe</li> </ul>	<ul style="list-style-type: none"> <li>• Check electrical connections</li> <li>• Check electrical connections integrity</li> <li>• Replace the probe</li> </ul>
E3	S3 probe broken or not properly connected (Red outdoor)	<ul style="list-style-type: none"> <li>• Erroneous electrical connections</li> <li>• False contact on connections</li> <li>• Broken probe</li> </ul>	<ul style="list-style-type: none"> <li>• Check electrical connections</li> <li>• Check electrical connections integrity</li> <li>• Replace the probe</li> </ul>

E4	<p><b>In cooling mode:</b> Insufficient refrigerant charge</p>	<ul style="list-style-type: none"> <li>Refrigerant gas leakage</li> </ul>	<ul style="list-style-type: none"> <li>Check refrigerant leaks</li> </ul>
E5	<p><b>In cooling mode:</b> High temperatures on heat exchanger in cupronickel</p> <p><b>In heating mode:</b> High temperature electric heater (only models with electrical resistance). High temperature probe heat pumps or overloaded compressor)</p>	<p>Possible causes in cooling mode:</p> <ul style="list-style-type: none"> <li>Not working sea water pump. Closed or obstructed sea water circuit: closed valve and obstructed strainers or sea water inlet</li> <li>Excessive refrigerant charge</li> <li>Not working pump transformer</li> <li>Broken temperature probes</li> </ul> <p>Possible causes in heating or heat pumps mode:</p> <ul style="list-style-type: none"> <li>Excessive refrigerant charge</li> <li>Defective temperature probes</li> <li>Fan not working or bad working</li> <li>Dirty air filter</li> <li>Obstructed outlet air grilles</li> <li>Fan not at maximum speed</li> </ul>	<ul style="list-style-type: none"> <li>Replace the pump</li> <li>Check pump functioning</li> <li>Check sea water circuit</li> <li>Clean sea water strainer</li> <li>Check fan</li> <li>Clean air filter</li> <li>Check refrigerant charge</li> <li>Check pump and transformer electrical connections</li> </ul>
E6	Low pressure failure	<ul style="list-style-type: none"> <li>Leakage of refrigerant</li> <li>Low pressure switch fault</li> <li>Defective electrical connections</li> <li>Defective probe</li> </ul>	<ul style="list-style-type: none"> <li>Check the correct functioning of the low pressure switch</li> <li>Check for refrigerant leaks</li> </ul>
E7	High pressure failure	<p>Possible causes in cooling mode:</p> <ul style="list-style-type: none"> <li>Seawater pump not working</li> <li>Closed or obstructed sea water circuit: tap closed or filter and sea inlet obstructed</li> <li>Sea water temperature too high</li> <li>Excessive refrigerant charge</li> <li>Pump transformer not working</li> <li>High pressure switch failure</li> <li>Defective pressure switch electrical connections</li> <li>Defective circuit board</li> </ul> <p>Possible causes in heating or heat pumps mode:</p> <ul style="list-style-type: none"> <li>Fan not working or bad working</li> <li>Obstructed outlet air grilles</li> <li>Fan not at maximum speed</li> <li>Excessive refrigerant charge</li> <li>High pressure switch failure</li> <li>Defective pressure switch electrical connections</li> <li>Defective circuit board</li> </ul>	<ul style="list-style-type: none"> <li>Check pump operation</li> <li>Check the sea water circuit</li> <li>Clean the seawater filter</li> <li>Check refrigerant charge</li> <li>Check the correct functioning of the high pressure switch</li> <li>Clean air filter</li> <li>Check pump transformer</li> <li>Check connections</li> </ul>

#### Operation

- When starting in cooling mode:  
Ventilation immediately starts and the compressor operates 3 min later
- When starting in heating or heat pump mode:  
the compressor starts 3 min later and the ventilation starts when certain conditions are reached after the compressor operation in order to avoid cold air release in the ambient.
- In cooling mode, if the probe in battery detects a temperature of <-1, after 10 min the compressor and the pump switch off and the fan continues to work; when the temperature is >-1, the compressor starts again.

#### 3.11. Infra red signal reception

- The system is able to receive the infra-red wireless commands from LCD handset or non LCD handset.

### 3.12. Buzzer

- Buzzer beeps in responding to valid button press or wireless signal reception.
- It beeps twice when the system is turned on, otherwise beeps once to all other valid acknowledgement

### 3.13. Backlight

- Back light colour changes according to the operating mode setting.

Operating Mode	Backlight Colour
Cool	Blue
Fan	Yellow
Dry	Pink
Heat	Reddish orange
Auto	Light violet

- The colour will change to red whenever there is system fault. Whenever the fault is cleared, backlight colour will return to original.
- If the unit is on, backlight will turn off 30 seconds after the last button press.
- If the unit is off, any button press will turn on the backlight and the screen display. The backlight will turn off 10 seconds after last button press.

### 3.14. Battery

A battery is used to sustain the operation of the internal real time clock when the power supply is cut off.

The installation of the battery is shown as follow:

